

**Danniflex 480 CPM**  
Technical & Service Manual

December 1998



*Registered to ISO 9001 for Quality Assurance*

**Danniflex 480 CPM**  
Technical & Service Manual

December 1998

**1.0 General Overview**

- 1.1 Introduction
- 1.2 Safety Precautions
- 1.3 Specifications
- 1.4 Symbols
- 1.5 Suggested Maintenance Schedule

**Maintenance Procedures**

**2.0 Covers**

- 2.1 Bottom Cover
- 2.2 Top Cover

**3.0 Cradle**

**4.0 Kneepot (potentiometer)**

- 4.1 Kneepot Cover
- 4.2 Kneepot Cable

**5.0 Motor**

**6.0 Ballscrew**

**7.0 Transformer**

**8.0 Controller Pendant**

- 8.1 Pendant Cable
- 8.2 Pendant Keypad
- 8.3 Pendant Printed Circuit Board
- 8.4 LCD Module

**9.0 Main Printed Circuit Board**

**10.0 Calibration**

- 10.1 Calibration Diagram

**11.0 Error Codes**

**12.0 Troubleshooting**

**13.0 Exploded View**

**14.0 480 Schematic**



In the event that European (EU)  
customers are unable to reach our  
national office, please contact  
Authorized Representative:  
MDCI, 58 Horsham Road, Crawley,  
West Sussex RH11 5PA, UK  
Tel: +44 (0) 1293 429608  
Fax: +44 (0) 1293 519121

For Technical Service Call:  
USA: 1.800.263.6004 International: 905.420.3303